

## การตั้งค่า Forward Port บน HUAWEI HG8247W5

1. พิมพ์ 192.168.1.1 แล้วกด Enter

- User Name = admin
- Password = ไล่ตามรูปในช่อง Default Password
- จากนั้นกด Log In



2. ไปที่ Advanced Configuration > Forward Rules > IPv4 Port Mapping



### 3. ตั้งค่าดังนี้

- กดปุ่ม New
- Type : เลือก User-Defined
- Enable Port Mapping : ทำเครื่องหมายถูกเพื่อเปิดใช้งาน
- Mapping Name : ตั้งชื่อ Profile ของการตั้งค่านี้ เพื่อให้รู้ว่าทำ Forward Port ไปใช้งานอะไร เช่น ตั้งว่า DVR เพื่อ Forward Port อุปกรณ์ DVR
- Internal Host : ใส่ IP Address ที่อุปกรณ์ที่ต้องการทำ Forward port ได้รับจาก Router เช่น DVR ได้รับ IP 192.168.1.108 ก็ใส่ IP นี้
- ตั้งค่าเรียบร้อยแล้วกดปุ่ม Apply
- จากนั้นให้กดปุ่ม Add

WAN Configuration

LAN Configuration

Security Configura...

Forward Rules

DMZ Function

IPv4 Port Mapping

Port Trigger Confi...

Application

WLAN

System Management

Maintenance Diagno...

### IPv4 Port Mapping

On this page, you can set port mapping parameters to set up virtual servers on the LAN network and allow these servers to be accessed from the Internet.  
Note: The well-known ports for voice services cannot be in the range of the mapping ports.

**1** New Delete

Mapping Name	WAN Name	Internal Host	External Host	Enable
----	----	----	----	----

**2** Type:  User-defined  Application

Application:

**3** Enable Port Mapping:

**4** Mapping Name:

WAN Name:

**5** Internal Host:

External Source IP Address:

**7** Add

**6** Apply Cancel

#### 4. ตั้งค่า Port ดังนี้

- Protocol : เลือกตามที่ใช้งาน ถ้าไม่แน่ใจให้เลือก TCP/UDP
- Internal port number : ใส่ Port ของอุปกรณ์ที่ต้องการทำ Forward Port
- External port number : ใส่ Port ของอุปกรณ์ที่ต้องการทำ Forward Port (หากใช้ True DDNS ให้ใส่ Port ที่ได้จาก True DDNS)
- ตั้งค่าเรียบร้อยแล้วปุ่ม Apply

### IPv4 Port Mapping

On this page, you can set port mapping parameters to set up virtual servers on the LAN network and allow these servers to be accessed from the Internet.  
Note: The well-known ports for voice services cannot be in the range of the mapping ports.

New Delete

Mapping Name	WAN Name	Internal Host	External Host	Enable
----	----	----	----	----

Type:  User-defined  Application

Application:

Enable Port Mapping:

Mapping Name:

WAN Name:

Internal Host:

External Source IP Address:  --

---

Protocol: 1

Internal port number: 2  --

External port number:  --

External source port number:  --

3 Delete

Add

4 Apply Cancel

5. หลังจากตั้งค่าเรียบร้อยแล้ว จะพบข้อมูลที่ตั้งค่าไว้ อยู่ที่ตารางด้านบน

### IPv4 Port Mapping

On this page, you can set port mapping parameters to set up virtual servers on the LAN network and allow these servers to be accessed from the Internet.  
 Note: The well-known ports for voice services cannot be in the range of the mapping ports.

Mapping Name	WAN Name	Internal Host	External Host	Enable
<input type="checkbox"/> DVR	1_TR069_INTERNET_R_VID_100	192.168.1.108	--	Enable

Type:  User-defined  Application

Application:

Enable Port Mapping:

Mapping Name:

WAN Name:

Internal Host:

External Source IP Address:  --

Protocol:  Internal port number:  --

External port number:  --  External source port number:  --