How to set up DDNS on GPON ZTE F668

1. Open a Browser and type http://192.168.1.1 and press ‘Enter’

   Type Username = admin/ Password = password and press ‘Login’



2. Click at ‘**Application**’



3. At '**DDNS'** menu, you can set up data referring to DDNS Service Provider and click '**Submit**' at the bottom