


การตั้งค่า WAN สำหรับ Xplor

1. พิมพ์ **192.168.1.1** ที่ Browser จากนั้นใส่ Username = **admin** / Password = **password** และกด **Login**



2. ที่หน้า Status เลือกเมนู WAN

The screenshot shows the BaudTec Home Gateway ADSL-VDSL Router status page. The browser address bar shows the IP address 192.168.1.1. The page title is "Home Gateway ADSL-VDSL Router". The left sidebar contains a navigation menu with the following items: Status, LAN, **WAN**, Services, Advance, Diagnostics, Admin, Statistics, and Logout. The main content area is titled "Router Status" and contains the following information:

This page shows the current status and some basic settings of the device.

| System | |
|----------------------|--------------------------------|
| Model Name | RN104R4GC-A3 |
| Uptime | 19:38 |
| Hardware Version | 7000-8Q3N-XX |
| DSL Uptime | 19:37:53 |
| PPPoE Uptime | 19:37:50 |
| CPU Usage (1.1GHz) | 23 % |
| Memory Usage (512Mb) | 46 % |
| Software Version | 104R4GC-A3_v1.2.43_TRU152V7 |
| DSL Firmware Version | v134g204 |
| DNS Server | 203.144.207.29, 203.144.207.49 |
| IPv4 Default Gateway | ppp1 |
| IPv6 Default Gateway | |


| DSL | |
|--------------------|------------------------------|
| Operational Status | YDSL2-17A Annex B, SHOWTIME. |
| Upstream Speed | 11775 kbps |
| Downstream Speed | 35319 kbps |
| CO Vendor ID | BDCM |

| LAN Configuration | |
|-------------------|---------------|
| IP Address | 192.168.1.1 |
| Subnet Mask | 255.255.255.0 |
| DHCP Server | Enabled |
| LAN MAC Address | 944696240893 |
| WAN MAC Address | 944696240894 |

| WAN Configuration | | | | | | |
|-------------------|---------|---------------|----------|-----------------|---------------|--|
| Interface | VPI/VCI | Encapsulation | Protocol | IP Address | Gateway | Current Connect Status |
| ppp0_vc0_0 | 0/100 | LLC | PPPoE | | | down 0sec / 0sec <input type="button" value="Connect"/> |
| ppp1_ptm0_0 | --- | --- | PPPoE | 124.120.230.116 | 124.120.230.1 | up 19:37:50 / 19:37:50 <input type="button" value="Disconnect"/> |
| vc1_0 | 0/104 | LLC | IPoE | | | down |
| ptm0_1 | --- | --- | IPoE | | | down |

3. เลือก PTM WAN และตั้งค่าดังนี้

- Interface ให้เลือก ptm0_0
- Channel Mode เลือก PPPoE
- Username / Password ใส่ Username และ Password ที่ลูกค้าใช้งาน
- Type เลือก Continuous
- Authentication Method เลือก AUTO
- เสร็จแล้วกด Apply Change



4. ถ้าเชื่อมต่ออินเทอร์เน็ตได้ที่หน้า Status ตาราง WAN Configuration จะแสดง IP Address ที่ถูกเชื่อมต่ออินเทอร์เน็ตได้

The screenshot shows the BaudTec Home Gateway router status page. The browser address bar shows 192.168.1.1. The page title is "Home Gateway ADSL-VDSL Router". The left sidebar contains navigation links: Status, LAN, WLAN, WAN, Services, Advance, Diagnostics, Admin, Statistics, and Logout. The main content area is titled "Router Status" and contains a table of system and DSL information. Below this is a "WAN Configuration" table with columns: Interface, VPI/VCI, Encapsulation, Protocol, IP Address, Gateway, and Current Connect Status. A red arrow points to the row for interface "ppp1_ptm0_0", which shows an IP Address of 124.120.230.116 and a Gateway of 124.120.230.1. The "Current Connect Status" for this interface is "up 19:37:50 / 19:37:50".

Router Status

This page shows the current status and some basic settings of the device.

| System | |
|----------------------|--------------------------------|
| Model Name | RN104R4GC-A3 |
| Uptime | 19:38 |
| Hardware Version | 7000-8Q3N-XX |
| DSL Uptime | 19:37:53 |
| PPPoE Uptime | 19:37:50 |
| CPU Usage (1.1GHz) | 23 % |
| Memory Usage (512Mb) | 46 % |
| Software Version | 104R4GC-A3_v1.2.43_TRU152V7 |
| DSL Firmware Version | v134g204 |
| DNS Server | 203.144.207.29, 203.144.207.49 |
| IPv4 Default Gateway | ppp1 |
| IPv6 Default Gateway | |

| DSL | |
|--------------------|-----------------------------|
| Operational Status | VDSL2-17A Annex B_SHOWTIME. |
| Upstream Speed | 11775 kbps |
| Downstream Speed | 36319 kbps |
| CO Vendor ID | BDCM |

| LAN Configuration | |
|-------------------|---------------|
| IP Address | 192.168.1.1 |
| Subnet Mask | 255.255.255.0 |
| DHCP Server | Enabled |
| LAN MAC Address | 944696240893 |
| WAN MAC Address | 944696240894 |

| WAN Configuration | | | | | | |
|-------------------|---------|---------------|----------|-----------------|---------------|---|
| Interface | VPI/VCI | Encapsulation | Protocol | IP Address | Gateway | Current Connect Status |
| ppp0_vc0_0 | 0/100 | LLC | PPPoE | | | down 0sec / 0sec Connect |
| ppp1_ptm0_0 | --- | --- | PPPoE | 124.120.230.116 | 124.120.230.1 | up 19:37:50 / 19:37:50 Disconnect |
| vc1_0 | 0/104 | LLC | IPoE | | | down |
| ptm0_1 | --- | --- | IPoE | | | down |

[Refresh](#)