


Set up UPnP for FiberHome AN5506-04-CG

1. Open a browser e.g. Chrome and type **192.168.1.1** then press **Enter**
 - Username = **admin**
 - Password = **password**
 - Press **Login**



2. It'll lead to Status page

secure | 192.168.1.1/login.html

Logout

Status	Network	Security	Application	Management
Device Information	Status » Device Information » Device Information			
Device Information	On this page, you can query device information.			
Wan Status	Device Information			
Lan Status	Software Version	RP2601		
Optical Info	Hardware Version	WKE2.134.285C3G		
VoIP Status	Device Model	AN5506-04-CG		
	Device Description	GPON		
	ONU State	O1(STATE_INIT)		
	ONU Regist State	INIT		
	LOID	fiberhome		
	CPU Usage	0.00%		
	Memory Usage	37.35%		
	Web Server port	80		
	CATV Enable	Enable		
	CATV Recived Power	-40.00dBm		
	CATV RF Power	-4.01dBmV		

3. Go to Application > UPnP > UPnP > Enable > Apply

secure | 192.168.1.1/login.html

Logout

Status Network Security **Application** Management

Application » UPnP » UPnP

On this page, you could configure UPnP enable/disable.

UPnP Enable Disable

Apply Cancel Remove Configuration