


Lock Channel for Samsung HS-1000C Receiver


1. Press “MENU” button on remote control




2. Select “Channel” and press OK



3. Press down arrow to “TV Channel Manager” then press OK



4. Enter your pin code: 1232



5. Page to edit your favorite TV channels




6. Press **Blue button** on remote control



7. Enter your pin code: 1232



8. Choose the channel to lock and then press OK



9. Behind the locked channel will have a lock key

