

Choose Network Mode on True Super Talkie 4G


1. On main screen, select **(Menu)**



2. Select **(Settings)**




3. And then **(Data usage)**



4. Choose to use Data from SIM Card or Wi-Fi > select **TRUE**


- TRUE = via SIM Card
- Wi-Fi = via Wi-Fi




5. Select (Options)



6. And then (Cellular networks)



7. Go down and choose (Preferred network type)



8. Preferred network type

- 4G/3G/2G Multi Mode= automatically select 4G (LTE) > 3G (WCDMA) > 2G (GSM) respectively
- 3G/2G Only Mode = automatically select 3G (WCDMA) and 2G (GSM)
- 3G Only Mode = select only 3G



9. Network mode sign



- If choose 4G/3G/2G Multi Mode = automatically select network starting from 4G
- If choose 3G => H or H+ will appear
- If choose 2G => G(GPRS) or E (EDGE) will appear