



Set up DDNS on AP D-Link DIR-895L

1. Open a Browser, type 192.168.0.1 > **do not enter the password** > press **Login**



2. Features > Dynamic DNS



3. Set up DDNS

- Enable Dynamic DNS : select Enabled or Disabled
- Enter information of using Host
- Once finished, press **SAVE**

Advanced >> Dynamic DNS Save **3**

Enable Dynamic DNS: **Enabled** **1**

Status: **Disconnected**

Server Address:	dyndns.com	dyndns.com 2
Host Name:	ahhagh1208.dyndns.com	
User Name:	ahhagh1208	
Password:	••••••••	
Time Out:	24	hours