


Select network mode for True SMART 4G MAX 4.0


1. On Home screen, select [Settings]




2. Select [More]



3. And then [Cellular networks]



4. Then [Select network mode]



5. Choose preferred network

- [GSM only]
- [WCDMA only]
- [WCDMA/GSM only]
- [LTE only]
- [Auto connect]

