


Set up Dynamic DNS for DASAN H662GR (No Wireless)

1. Type **192.168.1.1** then press **Enter**, Username = **admin**, Password = **password** and press **LOGIN**



2. On the left, select **Advanced Setup > Dynamic DNS**

- **Dynamic DNS:** select **Activated**
- **WAN Interface :** do not change
- **Service Mode :** select **Automatically**
- **Service Provider :** select service provider of Dynamic DNS
- **My Host Name :** enter Host name
- **Username :** enter Username that customer applied for Dynamic DNS (Host)
- **Password :** enter Password that customer applied for Dynamic DNS (Host)
- Press **APPLY**

