

## การสั่ง Restart จากหน้า Config ของ Cisco EPC3928D

1. เปิด Browser และในช่อง Address พิมพ์ **http://192.168.1.1** > พิมพ์ Username = **admin**  
, Password = **password** > และคลิกที่ปุ่ม **Log In**



DOCSIS WAN

Log In

User Name:

Password:

Language Selection:

2. เมนูด้านบนคลิก **Administration**, คลิกเมนู **Device Restart** พิมพ์ Password = password  
แล้วคลิกปุ่ม **Device Restart**

The screenshot shows the router's web interface. At the top, the 'Administration' menu is highlighted in green, with a red arrow pointing to it. Below it, the 'Device Restart' sub-menu is also highlighted. The main content area is divided into sections: 'Gateway Setup(WAN)', 'Gateway Access', 'Remote Access', and 'UPnP'. In the 'Gateway Setup(WAN)' section, the 'Working Mode' dropdown is set to 'Router Mode' and the 'Connection Mode' dropdown is set to 'DHCP'. Red arrows point to these dropdowns and their respective options. In the 'Gateway Access' section, the 'Local Access' sub-section is highlighted with a red box. The 'Current User Name' is 'admin', and the 'Change Current User Name to' field is also 'admin'. A red arrow points to this field. Below it are fields for 'Change Password to:' and 'Re-Enter New Password:'. At the bottom, the 'Save Settings' button is highlighted with a red arrow.