

Bottom

- 1) Port for Fiber Optic




Front**Back**

- 1) **CATV** : Coaxial port for RG6 for True Visions box
- 2) **LAN 1 - 4** : LAN port for RJ45 to device supporting LAN Card
- 3) **Phone 1 - 2** : telephone port for RJ11 to telephone set, Fax and other
- 4) **ON/OFF** : button power On-Off
- 5) **Power** : adapter port for DC12V/2A (11W)



Left

- 1) **Reset** : for resetting Router to factory setting, press and hold it for 10 second
- 2) **CATV button**
- 3) **USB port**


**Right**

- 1) Warranty sticker (warranty will end if sticker is damaged/ torn)



LED status FiberHomeAN5506-04-CG

No.	สัญลักษณ์	สี	ติดยิ่ง	กระพริบ	ไม่ติด
1	Power	เขียว	มีไฟเข้าอุปกรณ์	-	ไม่มีไฟเข้าอุปกรณ์
2	PON	เขียว	อุปกรณ์มีการลงทะเบียนกับระบบเรียบร้อย	อุปกรณ์กำลังทำการลงทะเบียนกับระบบ	อุปกรณ์ไม่ทำการลงทะเบียนกับระบบ
3	LOS	แดง	-	ไม่ได้รับสัญญาณ	ได้รับสัญญาณ
4	VOIP	เขียว	อุปกรณ์มีการลงทะเบียนกับระบบเรียบร้อย	-	อุปกรณ์ทำการลงทะเบียนไม่สำเร็จ
5	Phone1-2	เขียว	สัญญาณโทรศัพท์พร้อมใช้งาน	มีสัญญาณโทรศัพท์และกำลังใช้งานอยู่	ไม่มีสัญญาณโทรศัพท์
6	LAN1-4	เขียว	มีการเชื่อมต่ออยู่แต่ไม่มีการรับส่งข้อมูล	มีการเชื่อมต่ออยู่และมีการรับส่งข้อมูล	ไม่มีอุปกรณ์ต่ออยู่
7	CATV	เขียว	มีสัญญาณเคเบิลทีวีปกติ	สัญญาณเคเบิลทีวีอ่อน	สัญญาณเคเบิลทีวีอ่อนมากหรือไม่มีสัญญาณ
8	USB	เขียว	มีการต่ออุปกรณ์ที่ Port USB	-	ไม่มีการต่ออุปกรณ์ที่ Port USB
9	Internet	เขียว	การเชื่อมต่อกับ Internet ปกติ	มีการรับส่งข้อมูลอยู่	ไม่มีการเชื่อมต่อกับ Internet



Devices in a box

- 1) Router FiberHome AN5506-04-CG
- 2) Power Adapter
- 3) LAN cable
- 4) Telephone cable
- 5) User Manual

