


Restore Factory settings on True Kidz watch

1. At Home screen of Kidz watch (admin device), select [Manage]
2. At Manage page, tap [Menu] (3 dot sign)



3. Tap [Restore factory settings]



4. Tap [Restore]



5. Tap [Confirm] to start



6. After restoring factory settings, pair watch again
watch again



7. Screen if no pairing

