


First time configuration for HUAWEI DN8245W

1. Type 192.168.1.1 at Browser then press Enter

- User = user
- Password = HuaweiUser
- Press Log In



2. For first time Login, it's compelled to change the password and it should not be repeated with default password

3. Internet configuration : user/password for connecting the internet, press Next

DN8245W

Welcome to Huawei Home Gateway for connecting you to your family and friends.

Internet configuration Wi-Fi configuration Account management Configuration completion

Enter the bandwidth account and password provided by your carrier!

Bandwidth Account:

Bandwidth Password:

4. Wi-Fi configuration : set name and password of both 2.4G and 5G Wi-Fi then press Next

DN8245W

Welcome to Huawei Home Gateway for connecting you to your family and friends.

Internet configuration Wi-Fi configuration Account management Configuration completion

Set the Wi-Fi name and password


2.4G Wi-Fi Name: (1-32 characters)

2.4G Wi-Fi Password: Hide (8-63 characters or 64 hexadecimal characters)

5G Wi-Fi Name: (1-32 characters)

5G Wi-Fi Password: Hide (8-63 characters or 64 hexadecimal characters)

5. Account management : change Login password to configure Router, press Skip



DN8245W

Welcome to Huawei Home Gateway for connecting you to your family and friends.

Internet configuration Wi-Fi configuration **Account management** Configuration completion

Please change your login password!

User Name: user

Old Password:


New Password:

Confirm Password:

Password requirements

1. The password must contain at least 6 characters.
2. The password must contain at least two of the following combinations: Digit, uppercase letter, lowercase letter and Special characters (~!@#\$%^&*()-_+=\|[]{};:'"<.,->/?).
3. The password cannot be any user name or user name in reverse order.

6. Configuration completion : when finished, press Return to Home Page



DN8245W

Welcome to Huawei Home Gateway for connecting you to your family and friends.

Internet configuration Wi-Fi configuration Account management **Configuration completion**

Current network connection mode: Wi-Fi

If you have modified Wi-Fi parameters, try the connection again.
You can navigate to the home page and start using the Home Gateway.

7. Router's Configuration main page

The screenshot displays the configuration interface for a DN8245W router. The top navigation bar includes the Huawei logo, the model number 'DN8245W', and links for 'Fast Setting', 'user', and 'Logout'. A left-hand sidebar contains menu items: 'Home Page' (selected), 'One-Click Diagnosis', 'System Info', and 'Advanced Configuration'. The main content area shows the 'Network connection status: normal'. A central diagram illustrates the router's connections: an 'Internet' connection (green globe icon), 'Wi-Fi configuration' (blue antenna icon), and three device categories: 'Wi-Fi devices(1)' (blue smartphone icon), 'Wired devices(0)' (green computer icon), and 'Phones(2)' (green phone icon). The router unit is depicted with 'USB' and 'RESET' buttons labeled.