


Set up DMZ for ZTE F612C

1. Open a Browser e.g. IE, Chrome and type <http://192.168.1.1> then press **Enter**

- Username = **admin**
- Password = **password**
- Press **Login**



The screenshot shows a web browser window with the address bar displaying "ไม่ปลอดภัย | 192.168.1.1". The page header features the "ZTE" logo on the left and "F612C" on the right. The main content area contains a login form titled "Please login to continue..." with a language selector "中文". The form includes a "Username" field with "admin" entered, a "Password" field with masked characters, and a "Login" button. At the bottom of the page, the copyright notice reads "©2008-2017 ZTE Corporation. All rights reserved."

2. Go to **Application > DMZ Host** > choose to **Enable / Disable**

- To **Enable**: click (✓) at Enable
- To **Disable**: remove (✓) at Enable
- Then press **Submit**

