


# How to update Location on TRUE Lenovo 4G LTE 5.0


1. Go to 'Settings'




2. Select 'Mobile data'



### 3. Select 'Network operators'



### 4. Searching for available network



## 5. Select preferred network

