

## Access Setting Menu by a Shortcut Button on Remote Control for OPENTELE 4K-OP10C


1. Press **Mute** on Remote control > on TV screen will show a Mute sign



2. Press **V.format** on remote control to adjust resolution on TV screen



3. If in Radio mode > change to TV channel e.g. press TV channel: 33



4. Press **OK** on Remote control (on TV screen will show various programs e.g. sports, movies)



5. Press **FAV** on Remote control to view favorite program list



6. Press **GUIDE** on Remote control to view TV program guide







7. Press **INFO** on Remote control to view channel information



8. Press **Yellow** button on Remote control to change menu language and audio language



9. Press Blue button on Remote control to add favorite channel



10. Press SIGNAL on Remote control to check signal status while watching TV

