


Menu tab on Aircard4G MAXSURF 100Mbps and their functions

Home




On the upper right, the 3G or 4G network status, the network name, the signal strength, data connection, SMS and SIM card status.

The connection status and Disconnect button can be seen on the left tab.



Information>Device Information shows general information for the device



Information>Statistics shows all data usage including Upload & Download

The screenshot shows the 'true move 4G' mobile interface. The top navigation bar includes 'Home', 'Information' (highlighted), 'SMS', 'Phonebook', and 'Settings'. A left sidebar contains 'Device Information', 'Statistics' (highlighted), and 'Data Limit Settings'. The main content area is titled 'Statistics' and features a table with data usage information.

	Upload	Download
Speed	64B/s	25B/s

	Duration	Downloaded	Uploaded	Total Used Data
Current Connection	00:04:42	138.17KB	191.42KB	329.59KB
Current Month	00:05:51	142.54KB	193.55KB	336.09KB

Copyright © 1990-2013 ZTE Corporation. All rights reserved.

Information>Data Limit Settings


The screenshot shows the 'true move 4G' mobile interface. The top navigation bar includes 'Home', 'Information' (highlighted), 'SMS', 'Phonebook', and 'Settings'. A left sidebar contains 'Device Information', 'Statistics', and 'Data Limit Settings' (highlighted). The main content area is titled 'Data Limit Settings' and includes a toggle for 'Data Use Limit'.

Data Use Limit Enable Disable


Apply

Copyright © 1990-2013 ZTE Corporation. All rights reserved.

Information>Data Limit Settings enables you to set data usage limit by using time as the parameter



Information>Data Limit Settings enables you to set data usage limit by using the amount of data in the form of TB(Terabyte), GB(Gigabyte), MB(Megabyte) or percentage as the parameter.





SMS>Device SMS enable you to send an SMS from the Aircard

To compose a new message, select “NEW”.



One SMS can contain up to 765 characters






SMS>SMS Settings Validity = set time to send the

SMS Center Number = **do not change**

Delivery Report = Enable to report whether the receivers get SMS



Phonebook > All = all Contact


The screenshot shows the 'true move 4G' mobile application interface. At the top, there's a status bar with '4G TRUE-H T,full' and a battery icon. Below it, a navigation bar includes 'Home', 'Information', 'SMS', 'Phonebook' (highlighted in orange), and 'Settings'. On the left, a vertical menu lists contact categories: 'All' (highlighted in orange), 'Common', 'Family', 'Friend', and 'Colleague'. The main area is titled 'Phonebook (29/1100)' and features a search bar and buttons for 'New', 'Send Message', 'Delete', and 'Delete All'. A table lists various contacts with columns for Name, Save Location, Mobile Number, and Group. The contacts listed are: Balance, CallCenter, ChangePro, Check Pro, Chekbill, Chekpromo, Guru, iService, iVoice, and Net Pack. At the bottom, there are pagination controls showing page 1 of 3 and a 'Page:' field.

	Name	Save Location	Mobile Number	Group
<input type="checkbox"/>	Balance		#123#	-
<input type="checkbox"/>	CallCenter		+66891001331	-
<input type="checkbox"/>	ChangePro		9305	-
<input type="checkbox"/>	Check Pro		*935#	-
<input type="checkbox"/>	Chekbill		*9399	-
<input type="checkbox"/>	Chekpromo		*9399	-
<input type="checkbox"/>	Guru		*873#	-
<input type="checkbox"/>	iService		*877#	-
<input type="checkbox"/>	iVoice		*4952	-
<input type="checkbox"/>	Net Pack		*9000	-


Phonebook > -Common -Family -Friend -Colleague enables you to categorize your contacts

This screenshot is similar to the first one, but the 'Common' category in the left-hand menu is highlighted in orange. The main content area remains the same, showing the 'Phonebook (29/1100)' title, search bar, and buttons. The table of contacts is also present, though the specific contact names are not clearly visible in this view.


Settings>Network Settings (Dial-up Settings) cannot be changed while data is being used. You need to go back to the home page and disconnect data usage first.




Settings>Network Settings (Network Selection) cannot be changed while data is being used. You need to go back to the home page and disconnect data usage first.




Settings>Network Settings (APN) cannot be changed but a new one can be added by clicking “Add New”



Settings>Network Settings (APN) click “Add New”



Settings>Device Settings (PIN Management)



Settings>Device Settings (Update Management)

