


How to set up Dynamic DNS on AP D-link DIR-605L

1. Open a browser, type 192.168.0.1 in the address bar and then enter



2. Username = admin, Password = password and click Login






3. Click at ADVANCED




4. Select Maintenance





5. At Dynamic DNS > place a check mark at Enable DDNA > click Drop down > choose the service provider, then press <<</p>



6. Set up and press Save Settings

Host Name: enter Host name

Username: enter username

Password: enter password





7. Press Reboot Now





8. Wait for Reboot process around 10 seconds



9. Check at Status: Connected, it is ready to use now

