


Learn about Dual SIM Status Icons on iPhone XS, XS Max and iPhone XR

This setting can apply to iPhone XS, XS Max and XR or iPhone model that supports eSIM + nanoSIM or Dual SIM: nanoSIM + nanoSIM

1. On main screen, swipe screen down from top right



2. At Control Center, it'll show signal strength of both 2 carriers at the top left corner



3. Cellular Network

3.1. Signal strength


3.2. Cellular Plan Label :

- Pri = Primary is eSIM
- Pre = Prepay (manually set) is nanoSIM
(to view Cellular Plan Label, go to Settings > Cellular)


3.3. Carrier

3.4. Internet connection

- 4G = connect to the internet over Cellular data
- Fan sign = connect to the internet over Wi-Fi



4. Cellular plan order will depend on which one that Cellular Data is assigned:
- If Cellular data is assigned through Primary > Primary will be on top
 - If Cellular data is assigned through Prepay > Prepay will be on top instead of Primary



More information

Use Dual SIM that supports eSIM

- English = <https://support.apple.com/en-us/HT209044>
- Thai = <https://support.apple.com/th-th/HT209044>

Status Icons and symbols on iPhone

- English = <https://support.apple.com/en-us/HT207354>
- Thai = <https://support.apple.com/th-th/HT207354>