



## Set up LAN on AP Xplor RE1200R4GC-2T2R-V3


1. Type 192.168.2.1 then press Enter, User : **admin** / Password : enter letters from picture  
(if it's not clear, click at picture, it'll change but will be the same code)



2. Status page




### 3. Setting > Network



4. Set up as follows:

- **IP Address** : IP Address to access AP configuration page
- **DHCP** : ON to turn on DHCP, OFF to turn off DHCP
- **Client Range** : set Start IP Address and End IP Address that AP will distribute to connected device
- **Lease Time** : duration to clear DHCP and start to distribute new IP Address
- **SHOW CLIENT LIST** : show list of connected device
- Once finished, press **SAVE AND REBOOT NOW**



5. Wait for reboot process up to 100%

