


Select network mode for True SMART 4G MAX 5.5

1. On Home screen, select [Settings]




2. Select [More]



3. Select [Cellular networks]



4. And then [Preferred network Type]



5. Select preferred network

