How to update Location on True Phone Super 1

1. Select "Settings"

2. Go to "Connection Settings"

3. Select "Network selection"



4. Go to "Manual"